



- 1. Route cables through access panel to the left.
- 2. Use the provided 10-32 screws and sealing washers. Two extra screws and washers are inside the cavity. Fully tighten all eight screws, then back off one full turn.